



**PLS-10-002**  
Chain 4X12,2mm/m (250Kg hoists)



**PLS-12-002**  
Chain 5,0x15,1mm/m (500Kg hoists)



**PLS-11-002**  
Chain 7,1x20,5mm/m (1000Kg hoists)



**PLA-10-006** **QUIK LINK 4MM, ELV. FOR CHAINBAG.**  
Quick connection link to connect the chainbag safely to the chainbag bracket.



**PLA-10-008** **QUIK LINK 6MM, ELV. FOR CHAINBAG.**  
Quick connection link to connect the chainbag safely to the chainbag bracket.



**PLA-30-05**  
**Powercable 16A/400V/4p**  
Motor cable 16A, CEE 4p. To be used for direct controlled hoists. Available in several lengths.



**PLA-31-05**  
**Control Cable Low Voltage Hoists**  
6A, CEE 4p. To be used for low voltage controlled hoists. Available in several lengths.



**PLA-32-05**  
**Powercable 32A/400V/5p**  
Mains cable 32A, CEE 5p. To be used to connect your controls to the power system. Available in several lengths.



**PLA-33-05**  
**Multi cable, 16p. HARTING**  
To be used to connect up to 4 hoists - in combination with the 4-way break-out or break-in. Available in several lengths.




**PLA-34-01**  
**Break-in Cee-form to Harting, Direct Control**  
Adapter to connect a multi cable to 4 motor cables. 4 x 4p. Male CEE connector to female HARTING connector.



**PLA-34-02**  
**Break-out Harting to Cee-form, Direct Control**  
Adapter to connect 4 motor cables to a multi cable. Male HARTING connector to 4 x 4p. female CEE connector.



**PLA-34-04**  
**Break-out Harting to Cee-form, Low Voltage Control**  
Adapter to connect 4 motor cables to a multi cable. Male HARTING connector to 4 x 4p. female CEE connector. For low voltage hoists.



Low voltage setup



**PLA-40-001**  
Flightcase 250kg hoist



**PAE-A-FC500**  
Flightcase 500kg hoist



**PAE-A-FC1000**  
Flightcase 1000kg hoist



**PLA-50-003**  
Raincover 1000kg hoist single reeved



**PLA-50-007**  
Raincover 1000kg hoist double reeved